

LK CombiBoard EPS 14/18/30/50/70

Alternative Mounting with Double-Sided Tape

**NOTE!**

Do not use this method if the surface finish is ceramic tile.

Do not use this method if the installation includes a fiber-reinforced levelling compound.

General

If the surface finish is parquet or laminate flooring, you can attach the LK CombiBoard EPS board with double-sided tape. For limitations related to board thickness and other requirements, refer to the installation instructions **"On load-bearing floors with LK CombiBoard EPS 14/18/30/50/70"**.

- Use high-quality double-sided tape that is suitable for this application, for example:
 - Stokviks PC 030,
 - Tesa® Professional 4944 Extra Strong,
 - 3M GPT 020 or an equivalent product.

Procedure

1. Make sure that the substrate is clean and free from dust before you apply the tape.
2. Use double-sided tape that is 50 mm wide. Attach the board with three strips of tape: one strip in the center of the board and one strip at each end. For the easiest installation, apply the tape to the substrate first. Press each strip of tape firmly into place.
3. For concrete floors, consider applying a primer to bind dust and improve adhesion.
4. For the remaining installation steps, refer to the installation instructions **"On Load-Bearing Floors with LK CombiBoard EPS 14/18/30/50/70"**.



Illustration showing attachment using double-sided adhesive tape, with concrete and particleboard substrates, respectively.